



Panel lifter

APPLICATION	Computer / Equipment / Date centre Room
ACCESS FLOOR	ZT SC series Access Floor Systems
AVAILABLE DESIGN	Double cup lifter Single cup lifter



Description

The ZT double/single cup lifter can help to lift the raised floor panels quickly, easily and safely without damaging any of adjoining raised floor panels.

Where to use

ZT's double/single cup lifters are designed for use on all ZT access floor panels, including steel bare/ laminate panel surfaces. Woodcore panel and calcium sulphate panel

Easy To Use

The ZT's double panel lifters double suction cups are a press down activation suction cup which instantly holds and supports the access floor tile. To release simply pull on trigger and suction is released.

How To Use

When underfloor access is required, only those panels directly over the area of work should be removed. To remove the first panel, place the panel lifter in the centre of the panel, secure both suction cups and lift vertically. The surrounding panels can then be removed by placing a hand under the panel and lifting.

Caution

A panel lifter must be used to remove the first access floor panel. Do not 'hinge' a panel open or attempt to prise it out with a screwdriver or similar device.